

1. Using white gloves provided, carefully layout all brass or nickel fittings on a protected surface. Some assembly will be required using the included allen wrench.



2. Assemble the legs as shown.  
 Note: the tubing is cut to fit the depths of our Ventus and Terra sinks. On the underside of these sinks there are 2-4 recessed holes to accept the top 3/8" of each leg. Measure the center to center distance on the two front holes. This will be your measurement for locating the center of each wall connection.  
 Set the legs up so they are plumb, level and square against the wall and attach using the supplied screws and anchors (if needed).  
 If drilling into wood blocking or studs, please pre-drill the holes with a 7/64" bit. This will help with the installation of the softer brass screws. If going into drywall, use the supplied anchors and pre-drill using 3/16" bit.



3. Install sink top and bracket according to the sink model. The stone sinks are counterbored on the underside to accept the top 3/8" of the front legs. The collars directly under the sinks do not support any weight. These can be adjusted up against the sink bottom when you are done with the final assembly.

